

# Blue Star AC Error Code List

SL No.	Error Code	Error Description	Reset
1	A0	AC Over Voltage Error	Auto
2	A1	AC Under-Voltage Error	Auto
3	A2	Single Phasing Error	Auto
4	A7	Phase Imbalance Error	Auto
5	b0	Inv Compressor 1 Over Load Error	Auto
6	b1	Inv Compressor 2 Over Load Error	Auto
7	b6	Inv Compressor 1 Over Current Error	Auto
8	b7	Inv Compressor 2 Over Current Error	Auto
9	b8	Inverter Drive 1 Over Heat Error	Auto
10	b9	Inverter Drive 1 Over Heat Error	Auto
11	bA	Inverter Drive 1 Start Error	Auto
12	bb	Inverter Drive 2 Start Error	Auto
13	bC	ODU Fan Motor 1 Feedback Error	Auto
14	bd	ODU Fan Motor 1 Feedback Error	Auto
15	C1	Communication Error (Between ODU Control Board & ODU Power Board)	Manual Check
16	C2	Communication Error (Between ODU Control Board & ODU Fan Board)	Manual Check
17	C3	Communication Error (Between Master and slave ODUs)	Manual Check
18	C4	Communication Error (Between Master and slave IDUs)	ON IDUs supply & Manual Check
19	C5	Communication Error (Between IDUs & Wired Handset Remote)	Manual Check
20	C6	Auto-Addressing Error	Manual Check
21	C7	Communication Error( Inverter Drive 1)	Manual Check

<b>SL No.</b>	<b>Error Code</b>	<b>Error Description</b>	<b>Reset</b>
22	C8	Communication Error( Inverter Drive 2)	Manual Check
23	C9	Communication Error on some other IDU (Displayed on IDUs without communication error)	Manual Check
24	d0	Inverter Drive 1 DC Over Voltage error	Auto
25	d1	Inverter Drive 2 DC Oveer Voltage error	Auto
26	d2	Inverter Drive 1 DC Under Voltage error	Auto
27	d3	Inverter Drive 2 DC Under Voltage error	Auto
28	d8	Inverter Drive 1 Over Heat Error	Manual
29	d9	Inverter Drive 2 Over Heat Error	Manual
30	dA	Inverter Drive 1 Start error	Manual
31	db	Inverter Drive 2 Start error	Manual
32	dC	Inv Compressor 1 Over Current Error	Manual
33	dd	Inv Compressor 2 Over Current Error	Manual
34	dE	Inverter Drive Mismatch Error	Manual
35	E1	HP Switch Trip error	Auto
36	E2	HP Switch Trip for 3rd time in One Hour	Manual
37	E3	L P Error	Auto
38	E4	LP Error for 3rd time	Manual
39	E5	Inv Compressor 1 High DLT (Discharge Line Temperature)	Auto
40	E6	Inv Compressor 2 High DLT (Discharge Line Temperature)	Auto
41	E8	Inv Compressor 1 High DLT (Discharge Line Temperature) for 4th time	Manual
42	E9	Inv Compressor 2 High DLT (Discharge Line Temperature) for 4th time	Manual
43	Eb	ODU Fan Motor 1 feedback Error	Manual
44	EE	ODU Fan Motor 2 feedback Error	Manual
45	EC	Inv Compressor 1 Over Load Error	Manual
46	Ed	Inv Compressor 2 Over Load Error	Manual
47	F1	Ambient Temp. Sensor Failure	Manual Check
48	F2	DLT (Discharge Line Temperature) Inv. Compressor 1 Sensor Failure	Manual Check

<b>SL No.</b>	<b>Error Code</b>	<b>Error Description</b>	<b>Reset</b>
49	F3	DLT (Discharge Line Temperature) Inv. Compressor 2 Sensor Failure	Manual Check
50	F5	ODU Liq. Temp. (Hex1) Sensor Failure	Manual Check
51	F6	ODU Gas Temp. (Hex1) Sensor Failure	Manual Check
52	F7	ODU Liq. Temp. (Hex1) Sensor Failure	Manual Check
53	F8	ODU Gas Temp. (Hex1) Sensor Failure	Manual Check
54	F9	HP Sensor Failure	Manual Check
55	FA	LP Sensor Failure	Manual Check
56	Fb	Fire Alarm from ODU	Manual Check
57	Fc	Fire Alarm from IDU	Manual Check
58	U3	IDU Room Temp Sensor Failure (Displayed on IDU)	Manual Check
59	U4	IDU Liquid Temp Sensor Failure (Displayed on IDU)	Manual Check
60	U5	IDU Gas Temp Sensor Failure (Display on IDU)	Manual Check
61	U6	IDU Supply Temp Sensor Failure (Display on IDU)	Manual Check
62	U7	IDU Float Switch Error (Display on IDU)	Manual Check
63	U8	IDU Fan Motor Error (Display on IDU)	Manual Check
64	U9	Mode conflict Error (Display on IDU)	Manual Check