

VEVOR[®]

TOUGH TOOLS, HALF PRICE

Technical Support and E-Warranty Certificate

www.vevor.com/support

LED WALL PACK LIGHT INSTRUCTIONS

MODEL:BD-MSBD-100W /BD-MSBD-120W

We continue to be committed to provide you tools with competitive price. "Save Half", "Half Price" or any other similar expressions used by us only represents an estimate of savings you might benefit from buying certain tools with us compared to the major top brands and does not necessarily mean to cover all categories of tools offered by us. You are kindly reminded to verify carefully when you are placing an order with us if you are actually saving half in comparison with the top major brands.

VEVOR[®]

TOUGH TOOLS, HALF PRICE

LED WALL PACK LIGHT

Model:BD-MSBD-100W / BD-MSBD-120W



NEED HELP? CONTACT US!

Have product questions? Need technical support? Please feel free to contact us:

Technical Support and E-Warranty Certificate
www.vevor.com/support

This is the original instruction, please read all manual instructions carefully before operating. VEVOR reserves a clear interpretation of our user manual. The appearance of the product shall be subject to the product you received. Please forgive us that we won't inform you again if there are any technology or software updates on our product.




Warning-To reduce the risk of injury, user must read instructions manual carefully.

INSTRUCTIONS

NOTE: Before starting installation, please read instructions carefully.

Insulation class:I

Cos ϕ :>0.95 Height of installation \geq 1m







- Applicable for use in industrial areas, parking areas, facades, gardens & parks, landscapes.
- Fixture made of die-cast aluminum and tempered resistant PC protective shield.
- It is recommended that a qualified electrician is consulted or used for the installation of this luminaire and installed to the current edition of the IEE wiring regulations and Building regulations.
- This luminaire becomes very hot do not touch the luminaire until it has cooled down.

METHOD OF ERECTION

- Remove the diffuser from the base by releasing the captive screws around the edge of the luminaire.
- Use the body to mark the position of the screw holes onto the mounting surface.
- Drill the wall and fit the body using suitable fixing screws /wall plugs.
- Fix the luminaire to a suitable surface.Using of fixing methods available:Using the 4wall fixing semi holes provided.
- Sealant should be applied around the fixing screw heads to reduce water ingress if the luminaire is to be mounted externally.
- Secure the supply cable into the luminaire through the hole(s)provided ensuring that a cable gland is used to maintain the IP rating of the luminaire.
- Connect the cable to the terminal block ensuring correct polarity is observed and that if stranded cable is used no loose strands are left unconnected.This fitting must be earthed.

INSTALLATION SIZE

Model	L	W	E
A	316mm	174mm	166mm
B	362mm	232mm	186mm



PRODUCT PARAMETER

Model	BD-MSBD-100W	BD-MSBD-120W
Input	AC120V 60Hz	AC120V 60Hz
Power	100W	120W
Colour temperature	5000K	5000K
Luminous flux	10800LM	11000LM
IP rating	IP65	IP65
Induction type	Light sensing (after the ambient light becomes brighter, it will be extinguished within 5 seconds; When the ambient light dims, turn on for 1 second.)	

FAULT ANALYSIS

Questions	Analysis of causes	Countermeasure
The light is out	1、 Power cord connection is wrong. 2、 The photoreceptor is obscured.	1、 Connect the power cord correctly. 2、 Please manage the debris at the photosensor position.
The lights will not fit properly	Check whether mounting holes and clasps are correctly installed.	Drill and install the holes correctly according to the required dimensions.
The lights are dim.	Whether the voltage is correct.	Use the right power source.

FCC STATEMENT

Any Changes or modifications not expressly approved by the partly responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules.Operation is subject to the following two conditions:

- (1)This device may not cause harmful interference,and
- (2)this device must accept any interference received,including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver.

Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help. FCC

Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This transmitter must not be co located or operating in conjunction with any other antenna or transmitter.

Made In China

VEVOR[®]

TOUGH TOOLS, HALF PRICE

Technical Support and E-Warranty Certificate

www.vevor.com/support